

DBT-1713UD

Universal Disc
Transporter

DENON



BLU-RAY DISC TRANSPORT FOR MULTIPLE FORMATS, NETWORK AUDIO/VIDEO STREAMING

Enjoy Blu-ray discs, Super Audio CD and Network Content in Exceptional Sound and Picture Quality. With the Denon DBT-1713UD Blu-ray disc player, you can enjoy not only Blu-ray discs and DVDs in stunning sound and picture quality but Super Audio CDs and DVD-Audio discs, too. And that's not all, because the DBT-1713UD can also play music and video files stored on a PC and let you enjoy online content such as YouTube or the video on

demand service (VOD) Netflix*. The beautiful sound and picture quality is made possible by the meticulously engineered circuitry that has given Denon Blu-ray disc players their high acclaim. For ease of use the player can even be controlled via the Denon Remote App, when setup in combination with a Denon AV-Receiver of the 2012/2013 line up.

A Universal Blu-ray disc player that also supports Super Audio CD and DVD-Audio formats and streams content from the network

The DBT-1713UD plays not only Blu-ray discs and DVDs but a wide range of other optical media such as CDs, Super Audio CDs, and DVD Audio. You can essentially enjoy your entire disc library in high sound and picture quality. In addition the network functions gives access to wide variety of online contents like YouTube Leanback and Netflix video on demand distribution services. Further it is possible to enjoy music (MP3, WMA, up to FLAC HD 24bit / 192kHz), photo and video files incl. DivX HD stored on a network-connected device such as a PC or NAS (network attached storage).

NEW FEATURES

- Universal Blu-ray Disc Transport that also plays DVD, CD, Super Audio CD and DVD-Audio
- Fully shielded mechanism
- Quick response at loading and playback
- 4 independent block construction, for faithful playback of audio and video signals
- Fanless construction for silent operation
- Denon's high picture quality circuitry, to visually enhance your sources
- DLNA support for Network streaming (audio/video/photo)
- YouTube Leanback streaming and Netflix* incl. Netflix Super HD video on demand support
- Support for DivX Plus HD
- HDMI cable included

Denon Technologies for superior sound and picture quality
The direct Mechanical Ground Construction suppresses vibration and ensures high-quality HD sound and video. The disc mechanism, which also absorbs vibration, is mounted at the centre of the player to efficiently release unwanted vibration through the feet to the ground and support high-quality sound and picture playback.
The Independent Block Construction further supports this. The electronic circuits have been mounted in separate locations inside of the player to ensure that the different types of signals do not affect each other and cause electronic or magnetic noise. A further noise reduction has been achieved by a fan less construction.

STATE-OF-THE-ART DENON SOLUTIONS FOR MAXIMISING CONTENT QUALITY

- Network functions, to bring you a wealth of online content
 - Enjoy YouTube videos distribution services without a PC.
 - Enjoy music, photo, and video files stored on a network-connected device such as a PC or NAS.
- Supports HDMI 1.4 with 3D ready, Deep Color, "x.v.Color", High-Bit-Rate Audio output and HDMI control function
- USB port on the front
- Direct Mechanical Ground Construction, to suppress vibration and ensure high-quality HD sound and video
- Independent Block Construction, for faithful playback of audio and video signals
- Dolby TrueHD and DTS-HD Master Audio HDMI output
- Denon's high picture quality circuitry, to visually enhance your sources
- High-precision video encoder, and I/P Scalar for a cleaner picture and richer colours
- 1080p/24 video output, to bring out the full quality of film
- 3-D digital noise reduction
- HDMI source direct mode to output native resolution of the disc

Ease of Use
A USB port has been provided on the front panel for convenience when connecting a device containing compressed music or video files. The remote control with glo-keys and direct access buttons makes operation easy while the quick setup guide let you easily set up the unit without reading the full manual.

EASE-OF-USE

- User friendly GUI in multiple languages
- Glo-key remote controller
- Remote In/Out connection
- Remote lock mode

Denon is a trademark or registered trademark of D&M Holdings, Inc.

* Not available in all regions
All specs can be subject to change
Product available in Black

EAN	DBT1713UDBKE2	4582116367506
-----	---------------	---------------



Technical information			
Video		General	
Signal system	PAL / NTSC	Power supply	110 - 240 V, 50/60Hz
Audio		Power consumption	20 W (Power Saving Standby: 0.3 W) (Normal Standby: 0.5 W)
S/N	115 dB	Dimensions W x H x D	434 x 108 x 295 mm (incl. protrusions)
Total harmonic distortion	0.0025%	Weight	4.9 kg
Dynamic range	100 dB		

Ports		
Video	HDMI output	x 1
	Analog output (2ch, L/R)	x 1
Control	Ethernet	x 1
	USB port	x 1
	Remote control (IN/OUT)	x 1 / x 1

