## Let us entertain you









To get the full impact of the sound-tracks of the best movies today a capable subwoofer is a must.

Tight, clean bass together with the ability to play loud at even the lowest frequencies are what make movies and music more entertaining than ever before. The Jamo SUB 360 is able to do just that. The SUB 360 is equipped with a powerful 10-inch long-throw woofer housed in a unique slotted-port cabinet, employing an amplifier capable of delivering 360W of peak power.

With a cabinet volume perfectly matched to the weight of the loudspeaker cone, combined with a large voice-coil/magnet-system, and the addition of electronic equalization, frequency response reaches as low as 28Hz.

All delivered, of course, with maximum musical fidelity and entertainment factor. The volume control is placed on the front of the subwoofer, elegantly integrated into the design, with a soft blue light indicating the volume setting. The compact SUB 360 will add strong, well-defined bass with authority to any stereo- or home theater system. Deep bass in an elegant package.

Specifications **SUB 360** System Slotted port Woofer (mm / in) 254 / 10 Impedance (Ohm) 22 k Frequency Range (Hz) 28 - 200 Cut off Frequency (Hz) 40 - 200 Phase (deg.) 0 to -180 Switch Auto-On / Off Left / Right Line in Amplifier Rated output (W) 360 Stand-by power (W) < 0.5 Weight (kg / Lb) 18.9 / 41.7 Dimensions HxWxD (mm / in) 378 x 310 x 507 / 14.9 x 12.2 x 20.0 Black Ash, Dark Apple, Wenge Finishes Not all Finishes are sold in all countries.



